



# TIMBERLINE

• INTERNATIONAL BV •

## MAINTENANCE AND CLEANING INSTRUCTIONS

Maintenance and cleaning guidelines for the following floors:

- All solid and engineered floors of Original Chapel Parket
- All solid and engineered floors of AvanceFloors.

### **Warning**

- The first 30 days after installation avoid any moisture or water on the floor.
- Remove dirt only with a vacuum cleaner or use other dry cleaning methods.

### **Cleaning**

- Mop stubborn dirt away with Floorservice Parquet Cleaner.
- Mix approximately 100 ml Parquet Cleaner with 10 litres of clean water and clean the floor with a well squeezed mop
- Allow the floor to dry completely before walking on it.
- Floorservice Parquet Cleaner can be used for regular cleaning.

### **Maintenance**

- Depending on the intensity of use, treatment with Floorservice Maintenance oil will keep the floor in optimum condition.
- Use natural maintenance oil for dark and natural oiled floors.
- Use white maintenance oil for natural-white and white oiled floors.
- Use antique white maintenance oil for smoked and white oiled floors.
- First clean the floor with Floorservice Parquet cleaner as described above and allow it to dry completely.
- Apply Floorservice maintenance oil in small areas in an even layer with a cloth with the grain of the wood
- For larger areas we recommend to use a buffing machine.
- Dribble the maintenance oil in the shape of a snake and polish it in with a buffing machine using a thick white pad.
- 1 litre maintenance oil is sufficient for approximately 80 to 100 m<sup>2</sup>.
- Depending on ambient temperature and ventilation the drying time is 6 to 12 hours.
- For detailed information refer to the technical product sheets and the information on the packaging.
- Floorservice Maintenance oil can be used for 1 to 4 times per year depending on the intensity of use.

### **Frequency**

- |                             |   |  |
|-----------------------------|---|--|
| - Daily cleaning            | : | Floorservice Dry Clean Set                       |
| - Regular cleaning          | : | Floorservice Parquet Cleaner                     |
| - Maintenance normal use    | : | Floorservice maintenance oil 1 to 2 times a year |
| - Maintenance intensive use | : | Floorservice maintenance oil 3 to 4 times a year |